

### **VoIP Setup Guide for Netcomm NB9/NB9W Voip**

1. Open up your Web Browser (Internet Explorer)
2. Put in the IP address of the unit in to the address bar (192.168.1.1)
3. Log into the modem using the details below.
  - i. Username = admin
  - ii. Password = admin
4. Click on “Voice” on your left hand side and then “SIP”
5. Change the Interface name to **“ppp\_8\_35\_1-pppoe\_8\_35”**

6. You will only need to input the following details.

- i. Tick “Use SIP Proxy”

SIP Proxy = **sip.clickncallnow.com**

- ii. SIP Port = **5060**

SIP Proxy Domain = **sip.clickncallnow.com**

- iii. DispName = your 10-digit Clickncall username)
- iv. VoIP Phone Number = your 10-digit Clickncall username
- v. Auth ID = your 10-digit Clickncall username
- vi. Auth. Password = SIP Password (Supplied in Email)
- vii. RTP Payload = 96

7. Click on Apply

8. To double check everything is fine just Click back on “Home”

**If it says “Register to the SIP Proxy Succeed” you are up and running.**